




## LOGIN SCREEN



## MULTI SCREEN (DASHBOARD)




## LANDING CHANNEL




## CHANNEL LISTING






## INPUT FEED ISSUE







## CHANNEL NOT SUBSCRIBED



## CABLE DISCONNECTED



## FAVOURITE CHANNELS



## CLOSING THE APP

